1 Gather screwdriver, SAE allen set, and included components
To install on Camera Cage skip to 5.

2 Install locating pin
Attach Rod Clamp to bottom holes with button head screws.

3 Attach Mini Baseplate to camera bottom with one socket cap screw.

4 Mini Baseplate (BMC) attached directly to camera.

5 When using with Camera Cage (BMC), attach Rod Clamp to top holes and remove locating pin.

6 Attach Mini Baseplate to Camera Cage using (2) socket cap screws.

7 Mini Baseplate (BMC) attached to Camera Cage (BMC).